

Charging the Unit

The stock recorder comes with a cradle (sometimes called a docking station) that's used for charging the internal battery and for transferring data between the unit and the computer.

Charging the stock recorder

- 1. Connect the power cord to the port in the back of the cradle and plug the other end into the mains power.
- 2. Dock the Stock Recorder into the cradle to allow it to charge. A small green light on the front of the stock recorder will flash during charging.
- 3. Allow at least four hours to fully charge the battery from scratch.



Charging a spare battery

The cradle has a battery charger built into the back. When the stock recorder has only 5% remaining charge then a warning screen will suggest recharging the unit or changing to a new battery.

Changing the battery

Access the stock recorder battery by removing the panel on the back of the unit.

- 1. Exit FarmWorks and switch off the stock recorder.
- 2. Find the fasteners on the back of the unit, close to the bottom.
- 3. Turn the fasteners out and upwards.
- 4. Gently pry the panel from the bottom.
- 5. Pull out the battery and replace.



Learn the Keyboard





- 1. Switch on the stock recorder by holding down the *Power* button for a second.
- 2. Turn off by pressing the *Power* button once.
- 3. Press the *Shift* key once to type a capital letter. Press the *Shift* key twice to turn on *Caps Lock* so all letters are capitalized. Press the *Shift* key a third time to turn off *Caps Lock*.
- 4. To adjust the sound press the blue *Function* button twice, then press the + (plus) volume key in the centre to increase the volume or the (minus) key to decrease the volume. Press the blue *Function* button once more when finished.
- 5. As a general rule the *Enter* button should be used to move from one field to another instead of tapping on the screen. This ensures that the data is processed and saved correctly.
- 6. If the keyboard stops functioning look on the bottom toolbar on the screen to see if the *Ctrl, Shift* or *Alt* key has been left on by mistake. Push the offending key again to turn it off.